


1) Подключаемся к Wi-Fi, называется **Wive-NG-HQ-5GHZ-928/Wive-NG-HQ-928**, сеть без пароля


2) Обновляем прошивку

Administration -> Management -> Firmware update -> check -> install -> ждём пока загрузится и установится прошивка



3) Ставим пароль на пользователя Admin, пароль ставим admin1234

Administration -> Management -> User Settings -> меняем пароль -> "apply"



4) Открываем доступ по 443 порту для офисного ip (**85.142.169.2**)

Firewall -> Firewall -> Создаём правило -> add -> apply

Interface - WAN, protocol - TCP, scr IP - **85.142.169.2**, dst Ports 443

Warning!
Recommended to set the encryption and/or change your password for the wireless network. [Go to settings](#)

Firewall Settings

You can set up firewall rules to protect your network from viruses, worms and other malicious activity on the Internet.

Port Forwarding Settings

Transit traffic filter settings

Connection to local services

Accept incoming connection IPv4 Enabled

Interface	Protocol	Src IP	Src Ports	Dst Ports	Comment	Action
No IP / MAC / port filtering rules yet						
WAN	TCP	85.142.169.2		443	office	Add

DMZ Settings

Other Settings

Limit TCP session per ip: 0 (default: 0 - disabled)

Accept icmp echo from WAN network Enabled

Apply Cancel Reset